Factory default settings









Your connect.control devices will appear in the App automatically, the remote control is independent and will not show.



auroralighting.com/connect.control

LEVEL 4 Overview







LEVEL 4 Edit Scenes





Tap the Scenes icon, at the bottom of the System screen



The 5 scene presets can be edited, do not delete the scenes as these are preset.



ap a scene to recall, hold to access the editing screen



Choose to adjust each light individually, or the whole room. The remote buttons 1-5 will now recall the updated scene



LEVEL 4 Create Schedules





auroralighting.com/connect.control

LEVEL 4 Using Music Mode

SMART LIGHTING SPACES

For those vibrant evenings, we have included a music feature on our app.

This offers a simple level of automation, enabling lighting to sync with the rhythm of music, randomly adjusting the colour sequences of your lights.





"I've accidentally deleted scenes!" "I've added devices into the wrong room!"

The great thing with this simple range is, if you adjust anything that you can't seem to resolve, then switching on/off at the wall 6 times will bring devices back to the factory settings.

To do this switch off for 3 seconds and on for 1 second, 6 times, when the lamp has successfully been reset it will flash 3 times, for the Strip controller you can reset by pressing the reset button on the White control module.

The devices will go back into room 1 and the 5 preset scenes and you can start again, or visit the Aurora website for more FAQs.



